

JEM INTERNATIONAL, INC.
PHONE: 913-441-4787 FAX: 913-441-1711

JM-FF-ED GROSS WEIGH BAGGING SCALE				
	PART #	DESCRIPTION	CODE	
	0176431	Enclosure 6 x 4 x 5 Fiberglass		
	1425194	Muffler 1/8 NPT		
	0015480000	Beam clevis		
	0024257909	Seal chute GB white	R	1
	0024257910	Chute seal	R	1
	0024257911	Chute seal plate MS		
	0024257913	Chute seal plate SS		
	0034053626	Spacer lower short		
	0034053627	Spacer lower short SS		
	0379823601	Slide bar MS		
	0379823602	Slide bar SS		
	0379833601	Slide bar spacer MS		
	0379833602	Slide bar spacer SS		
	0379943601	Gate stop bar MS		
	0379943602	Gate stop bar SS		
	0397083501	Shipping clip MS		
	0418176601	Regulator Slide handle MS		
	0418176602	Regulator Slide handle SS		
	0418183501	Regulating slide plate MS		
	0418183502	Regulating slide plate SS		
	0423943603	Sway Link MS		
	0423943604	Sway Link SS		
	0423955501	Sway Bracket MS		
	0423955502	Sway Bracket SS		
	0447973601	Dust skirt bar MS		
	0447973602	Dust skirt bar SS		
	0467603501	Restrictor plate MS		
	0467605501	Restrictor plate SS		
	0488133502	Plate baffle AO SS		
	0467605501	Plate restrictor SS		
	2795900010	Switch wand non-metalic		
	3600500000	Rod, gate adjust MS		
	3600500001	Handle adjust SS		
	3700510000	Foot switch		
	3770190002	bracket AC 2 dig JM MS		

3770190003	Bracket AC 2 dig JM SS		
3770330040	Filter Regulator		
3770330041	Regulator		
3770340000	Control box MS		
3770340005	Plate control box JM MS		
3770340006	Plate control box JM SS		
3770700000	Housing MS		
3770720000	Housing SS		
3770710000	Feedgate handle MS		
3770710001	Feedgate handle SS		
3770800000	Weight rod MS		
3770840000	Prox switch bracket complete MS		
3770840001	Proximity bracket		
3770870001	Valve replacement	R	1
3900140000	Rear clevis (2 speed only) MS		
3900140001	Rear clevis SS		
4425120000	Special washer		
4425150000	Wingnut		
5000230002	Bracket load cell RH JM SS		
5000320001	Angle bracket load cell RH SS		
5000230003	Bracket load Cell LH JM SS		
5418150001	Top chute MS		
5418220001	Regulating slide MS		
5418220002	Regulating slide SS		
5423910001	Chute gate MS		
5423910002	Chute gate SS		
5454480002	"H" bracket MS		
5454480004	"H" bracket SS		
7052250000	Feed gate bearing		
7061150000	Rod end bearing (2 speed)		
7061400000	Rod end 1/4 RH		
7623140002	Spout bearing MS		
7675400003	Flow decal		
7791780000	Dust skirt fabric 5.5 x 50 cir.	R	1
7800510000	Proximity switch		
7800550250	Load Cell #250, standard series		
7800550604	Summing box		
7800650001	Knob		
8282509999	Vent dust port		
8333260000	Spout cylinder MS		

	8333260003	Spout cylinder SS		
	8333260002	Clevis spout		
	9250400000	Weight box cover		
	9300000001	Scale box JM 36 x 30 x 36		
	83CQ2B50-PS	Seal kit 2 speed gate cylinder MS or SS	R	2
	83NC1A200-PS	Seal kit, spout MS cylinder	R	1
	83NQ250GDF0145	Gate cylinder (2 speed) MS	R	1
	83US19149	Gate cyliner (2 speed) SS		
	PART #	D E S C R I P T I O N	CODE	Simplex
		465 GSE Controller		
	24660B-122AO	I/O module 2 input/2 output	R	1
	24660B-130AO	I/O module 4 position SBM. AC	R	1

R=RECOMMENDED SPARE PARTS

When ordering parts be sure to advise scale


construction (ex. Mild steel, stainless) and serial number

Some part pictures may differ from your scale as we do update parts occassionally

JM-FF-ED Gross Weigh Bagging Scale


Cylinder 2 speed
83NQ250GDF0145 MS
83US19149 SS
Kit
83CQ2B50-PS

Dust skirt
7791780000




Valve assembly
3770870000

Valve solenoid
3770870001



Filter regulator ass'y
3770330046

465 Controller



Cylinder Bag clamp
8333260000 MS
8333260003 SS
Kit
83NC1A200-PS

Bearing
7623140002

JEM INTERNATIONAL, INC.**PHONE: 913-441-4787 FAX: 913-441-1711**

JM BELT FEEDER PARTS LIST					
PART #	DESCRIPTION	CODE			
0012003542	Motor 3/4HP 3 Phase				
0020401914	Sprocket				
0020000003	Sprocket				
0023487924	Belt BF-14 endless white	R	1		
0498437801	Belt seals	R	3		
0498437815	Seal BF-14 side UHMW 2 3/4	R	2		
0498437820	Seal BF-14 end UHMW 2 3/4	R	1		
3600000000	Housing				
3600010000	Housing SS Contact BF				
3600080000	Spring				
3600160000	Scraper				
3600160002	Scraper SS				
3600160001	Scraper bracket				
3600160003	Scraper bracket SS				
3600170006	Drip pan				
3600180000	Bracket rear bearing				
3600190000	Bracket front bearing				
3600260000	Chute				
3600310000	Belt support plate				
3600310001	Belt support plate SS				
3600490000	Space tube				
3600500000	Handle adjust				
3600510000	Bracket flow adjust				
3600510002	Bracket ff gate stop				
3700581401	Gear Box				
5022640000	Belt	R	1		
5422120000	Access door				
5422150001	Flow gate				
5422150006	Flow gate SS				
6034500000	Toggle clamp				
78PBF068	Bearing flow gate				
7144050000	Bumper	R	2		
7623180000	Bearing				
7800650001	Knob				
8332820002	Front Clevis				
8332830003	Rear Clevis				
8332850000	Cylinder gate single speed JM	R	1		

R=RECOMMENDED SPARE PARTS

When ordering parts be sure to advise scale construction (ex. Mild steel, stainless)

BELT FEEDER

Motor 3/4HP 3 Ph
0012003542

Gear box
3700581401

Not Shown
Sprockets
0020401914
0020000003

Rear Clevis
8332830003

Knob
7800650001


Cylinder gate
single speed JM
8332850000

Handle adjust
3600500000

Flow gate
5422150001

Bearing flow gate
78pbf068

Front Clevis
8332820002



Bracket ff gate stop
3600510002

Bracket flow adjust
3600510000

Space tube
3600490000

Bumper
7144050000


Toggle clamp
6034500000

Bearing
7623180000

Access door
5422120000

Drip pan
3600170006

Chute
3600260000



Belt
5022640000

Housing
3600000000


NOT SHOWN
Scraper
3600160000

Bracket rear bearing
3600180000

Scraper bracket
3600160001

Spring
3600080000

Belt seals
0498437801



Belt support plate
(not shown)
3600310000

Bracket front bearing
3600190000